

INSTALLING MOLDING

(All the way to the ceiling)

Before putting up the cabinets, determine what molding you're using and how much space you need to leave for the molding.

Example in CCM10-B ::::: Installing Type: Molding all the wall to the ceiling



(Shown CCM10-B)



(Cut the back end piece, Leave 1/4-1/2")



Before hanging the wall cabinet, put a wood block in every corner of wall cabinets for nailing purpose.



CCM10-B is 3" So make sure to leave 3" for molding.



Apply the Molding in front of the wood block



Use 18 or 23 Gauge to nail the molding. Finished!