

ASSEMBLY INSTRUCTIONS

BASE BLIND CORNER CABINET

Part	Descriptions	Qty	Part	Description	Qty	Part	Description	Qty
A,B,C,D	Drawer Parts	1	J	Back Panel	1	P	Screw $\phi 3.5 \times 12$	22
E	Slide With Screws	1	K	Toe Kick	1	Q	Corner Brace	4
F	Face-frame with Door	1	L	Support Panel	1	R	Shelf	1
G	Side Panel	2	M	Screw $\phi 3.5 \times 25$	18	S	Shelf Clip	4
H	Bottom Panel	1	N	L-Shaped Steel	5	T	Glue (not included)	1
I	Rail	2	O	L-Shaped Steel	3			

This instructions applies to the following items: **BBC39/42**.



Wood glue are required for assembly. Wood glue applied to each notching area for stability (wood glue not included)

STEP 1: Add a Bead of Glue to the Face Frame and each notching area needed.

STEP 2: Slide-in the Sides to the Frame.

STEP 3: Slide-in the Top and Bottom.

STEP 4: Slide-in the Back to the Cabinet Box.

STEP 5: Secure the Corners of the Box by using the L-Shaped Steel.

