

# ASSEMBLY INSTRUCTIONS

## BASE BLIND CORNER FULL HEIGHT CABINET

Part	Descriptions	Qty	Part	Description	Qty	Part	Description	Qty
A	Face-frame with Door	1	F	Back Panel	1	K	L-Shaped Steel	3
B	Side Panel	2	G	Toe Kick	1	L	Screw $\phi 3.5 \times 12$	28
C	Bottom Panel	1	H	Support Panel	1	M	Corner Brace	4
D	Rail	2	I	Screw $\phi 3.5 \times 25$	18	N	Lazy Susan	1
E	Rail	1	J	L-Shaped Steel	8	O	Glue (not included)	1

This instructions applies to the following items: **BBC45/48FH.**



\*\*Wood glue are required for assembly. Wood glue applied to each notching area for stability (wood glue not included)\*\*

**STEP 1:** Add a Bead of Glue to the Face Frame and each notching area needed.

**STEP 2:** Slide-in the Sides to the Frame.

**STEP 3:** Slide-in the Top and Bottom.

**STEP 4:** Slide-in the Back to the Cabinet Box.

