

ASSEMBLY INSTRUCTIONS

BASE DRAWER CABINET

| Part | Descriptions | Qty | Part | Description | Qty | Part | Description | Qty |
|---------|-------------------|-----|------|----------------------------|-------|------|----------------------------|-----|
| A,B,C,D | Drawer Parts | 3 | I | Rail | 2 | N | L-Shaped Steel | 2 |
| E | Slide With Screws | 3 | J | Back Panel | 1 | O | Screw $\phi 3.5 \times 12$ | 16 |
| F | Face-frame | 1 | K | Toe Kick | 1 | P | Corner Brace | 4 |
| G | Side Panel | 2 | L | Screw $\phi 3.5 \times 25$ | 17/18 | Q | Glue (not included) | 1 |
| H | Bottom Panel | 1 | M | L-Shaped Steel | 4 | | | |

This instructions applies to the following items: **DB12-3~DB36-3, DB15~DB36, DB30-2.**



Wood glue are required for assembly. Wood glue applied to each notching area for stability (wood glue not included)

STEP 1: Add a Bead of Glue to the Face Frame and each notching area needed.

STEP 2: Slide-in the Sides to the Frame.

STEP 3: Slide-in the Top and Bottom.

STEP 4: Slide-in the Back to the Cabinet Box.

STEP 5: Secure the Corners of the Box by using the L-Shaped Steel.

