

O338424,O339024,O339624

ASSEMBLY INSTRUCTIONS

Getting started:

prepare a protection layer, a screwdriver

STEP 1: Joint side panel with top panel

STEP 2: Joint back panel with side panel

STEP 3: Joint side panel with middle & bottom panel

STEP 4: Joint side panel with middle & bottom panel











STEP 5: Fix shelf board

STEP 6: Attach frame on and toekick board

STEP 7: Joint the drawer together, then install the drawer guide.

STEP 8: Fix door&drawer head onto the frame and adjust the cover-space

| PARTS LIST | | |
|------------|---------------------------|-----|
| NO. | Description | QTY |
| A | SIDE PANEL | 2 |
| B | TOP&BOTTOM PANEL | 3 |
| C | BACK PANEL | 1 |
| D | FACE FRAME | 1 |
| E | TOE KICK | 1 |
| F | DRAWER BOX FRONT AND BACK | 6 |
| G | DRAWER BOX SIDE | 6 |
| H | DRAWER BOX BOTTOM | 3 |
| I | DRAWER HEAD | 3 |
| J | CABINETS DOOR | 2 |
| K | ADJUSTABLE SHELF | 2 |

| 10 | 1/2" HINGE | 4 |  |
|-----|--------------------------------|-----|---|
| 9 | 3/4" ROUND HEAD SCREW | 4 |  |
| 8 | BUMPER | 16 |  |
| 7 | 1" ROUND HEAD SCREW | 12 |  |
| 6 | Epoxy Slide | 3 |  |
| 5 | SHELF CLIP | 4 |  |
| 4 | 9/16" ROUND HEAD SCREW | 68 |  |
| 3 | CLEAT | 17 |  |
| 2 | 1" FLAT HEAD SCREW FOR CARCASS | 46 |  |
| 1 | 9/16" flat head screw | 30 |  |
| NO. | Description | QTY | PICTURE |

HARDWARE LIST

