

WER42,WER36,WER30

ASSEMBLY INSTRUCTIONS

Getting started:

prepare a protection layer, a screwdriver

STEP 1: Joint right side panel with right side back panel

STEP 2: Fix the bottom/top panel on


STEP 3: Joint left side panel with left side back panel

STEP 4: turn the carcass stand,Insert back panel through the groove

STEP 5: Attach face frame(long and short), then screw up


STEP 6: Put on the adjustable shelves

STEP 7: Hinge the door onto the face frame and adjust the cover-space




PARTS LIST		
NO.	Description	QTY
A	SIDE PANEL	2
B	SIDE BACK PANEL	2
C	TOP&BOTTOM PANEL	2
D	BACK PANEL	1
E	FACE FRAME	1
F	FACE FRAME	1
G	ADJUSTABLE SHELF	2 OR 3
H	CABINETS DOOR	2


STEP:1




STEP:2




STEP:3




STEP:4




STEP:5












STEP:6



STEP:7



9	135 DEGREE HINGE	3 OR 2	 135° hinge
8	3/4" ROUND HEAD SCREW	12 OR 4	 3/4" round head screw
7	BUMPER	6	 Bumper
6	165 DEGREE HINGE	3 OR 2	 165° hinge
5	SHELF CLIP	24 OR 16	 Shelf clip
4	9/16"ROUND HEAD SCREW	88	 9/16" round head screw
3	DOWEL	4	 Dowel
2	1"FLAT HEAD SCREW FOR CARCASS	6	 1" flat head screw
1	CLEAT	22	 Cleat
NO.	Description	QTY	PICTURE

HARDWARE LIST